Whats in the box?

- 1× Penguin Mechanical Keyboard
- 1× Keycap Puller Tool
- 1× Switch Puller Tool

- 1× 6ft Braided Cable

HOTKEY INDEX

Primary Hotkeys

F1	FN + 1	**F8**	FN +8	**Page Up**	FN + U	**Scroll Lock**	FN + [
F2	FN + 2	**F9**	FN +9	**Page Down**	FN + O	**Pause**	FN +]
F3	FN + 3	**F10**	FN +0	**Left Arrow**	FN + J	**Insert**	FN + ;
F4	FN + 4	**F11**	FN + -	**Down Arrow**	FN + K	**Delete**	FN + '
F5	FN + 5	**F12**	FN + =	**Right Arrow**	FN + L	**Home**	FN + N
F6	FN + 6	`	FN + ESC	**Up Arrow**	FN + I	**End**	FN + M
F7	FN + 7	~	SHIFT + ESC	**Print Screen**	FN + P	**Mute**	FN + ,

Volume Decrease   FN + .

Other Commands

Restore Keyboard to Factory Default Settings (Hold for 10 seconds)	FN + R
Swap FN and Caps Lock key functions	FN + Caps
Enable/Disable Penguin Key	FN + Penguin Key
Toggle between **N-KEY Mode** (Default) and **6-Key Mode** *Note: Keep this setting to N-KEY if unsure what this means.*	FN + Menu

Built-in LED Effects

Breath	· RGB Breathing · Breathing single color · Solid single color	FN + F	**Wave #1**	· Wave effect with fade · Wave effect with less fade · Circular wave effect	FN + C
Touch	· LEDs ripple outward from pressed keys · LEDs of pressed keys light up and fade · LEDs spread to the entire row of pressed keys	FN + G	**Wave #2**	· Bouncing wave effect · Solid single color · Waves from sides meet in middle	FN + B
K-Effect	· All keys fading in and out randomly · All keys turning on and off randomly · Each row fading in and out	FN + V	**Drawing**	· Heartbeat sensor effect · Kamehameha effect · Matrix-style effect	FN + H

LED Light Settings

Change LED Animation Speed	Slower	FN + A	**Change LED Backlight Color** (Cycles through 8 colors)	FN + X
	Faster	FN + D		
Change LED Brightness Note: The indicator LED will blink 5 times when the minimum or maximum values of LED Speed or Brightness are	Increase	FN + W	**Change LED Animation Direction**	FN + Z
	Decrease	FN + S	**Turn off Keyboard Backlight**	FN + B